

# STRATASEAL™ HR protects occupied medical laboratories

When it was decided that a courtyard would be implemented into the WUSM/BJC Medical complex it didn't take long for the design team to realize that "waterproofing" was going to be a major consideration.



### PROJECT DETAILS

Washington University School of Medicine, Bio-Med Building

### LOCATION

St. Louis, Missouri

### PRODUCTS USED

STRATASEAL™ HR

### CHALLENGE:

Waterproofing and protecting the occupied space below while still allowing construction to continue.

Jim Taylor with ABS Consulting was assigned the task of finding a waterproofing system for the plaza deck that would protect the occupied space below housing medical school laboratories.

The construction schedule of the bio-med building also impacted the finish landscape project. The horizontal structural slab, designed as the plaza footprint, first needed to serve as a staging area for the building components of the multi-story building. At the same time, interior finish work was underway below the plaza and therefore immediate waterproofing was a mandate.

# STRATASEAL™ HR protects occupied medical laboratories

### **SOLUTION:**

The solution was to apply a 90 mil application of CETCO's STRATASEAL HR hot rubberized asphalt with protection course and pour a temporary topping slab. Upon completion of construction the topping was removed and the STRATASEAL HR "215 mil" system was installed. The main benefit to the HR system is the total adhesion to the substrate and thus the elimination for moisture migration under the membrane, common with sheet applied systems. To add to the water management of the plaza deck the CETCO AQUAD-RAIN product was installed and incorporated into the deck drains.

### **RESULT:**

The result yielded a monolithic water tight membrane system ready to receive the overburden of the plaza fountain, walkways and greenscape areas.

North America: 847.851.1800 | 800.527.9948 | [www.CETCO.com](http://www.CETCO.com)

UPDATED: JULY 2015

© 2015 CETCO. IMPORTANT: The information contained herein supersedes all previous printed versions, and is believed to be accurate and reliable. For the most up-to-date information, please visit [www.CETCO.com](http://www.CETCO.com). CETCO accepts no responsibility for the results obtained through application of this product. CETCO reserves the right to update information without notice.

